






OnePOD

Wireless Zone Manager
& LED Emitter Dongle
DBD701 & DBD703



- 1 Determine your range settings by consulting the illustration to the right for guidance. Turn the knob to the desired setting by hand or using the key fob tool included with the OneKEY.




Note: All distances are approximate. The shape and distance of the field can be altered by ferrous objects near the Zone Manager (such as structural steel pillars). The field also extends upwards. Keep these factors in mind when installing and setting the range of the field.

- 2 Determine your Alarm setting.


Sensors will begin to alarm when they enter the Alarm Zone. When sensors leave the Alarm Zone, the alarm will shut off according to the mode setting

- **(A) Warning Mode:** Alarms shut off after it leaves the Alarm Zone
- **(B) Continuous Mode:** Alarms continue until it times out (duration is specific to the sensor).


Note: Alarms can be deactivated as covered in the instructions for that sensor.



- 3 Plug the YLR52 power supply (requires region specific YC cable) into the 2-pin port in the Zone Manager.




- 4 If installing the LED Emitter (DBD703), plug that into the 3-pin port in the Zone Manager.




- 5 Determine how the Zone Manager will be mounted. If mounting with hardware consult the included Mounting Template for hole locations. Use hardware appropriate for the 8mm diameter screw holes or the M4 x 0.7 threaded inserts.

Note: If mounting to a ceiling and threading hardware into the Zone Manager, ensure that some type of threadlocker (i.e. Loctite Threadlocker Blue) is used to prevent loosening through vibration.




- 6 Connect the YC power cable to the power supply and plug it into a power outlet.




- 7 The LED on the Zone Manager will illuminate Gold.


Note: If at any time the LED flashes yellow instead of remaining constant, this indicates that the Zone Manager has lost power and is running off of battery.




- 8 Once it is determined how and where the Zone Manager will be mounted, introduce a sensor and device (following the steps outlined in the sensor instructions) to the Alarm Zone to test the settings. Adjust the setting as desired




- 9 Mount the Zone Manager as previously determined.




- 10 If using the LED Emitter, determine where it will be mounted. Use the provided alcohol wipe to clean the area where it will be mounted.




- 11 Peel the clear film from the adhesives on the LED emitter.



- 12 Place the LED emitter in the predetermined location and apply pressure for at least 10 seconds.



- 13 The LED Emitter will illuminate.



FCC Compliance
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Regulatory Compliance
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Élimination d'une batterie au feu ou dans un four chaud, ou écrasement ou coupure mécanique d'une batterie, qui peut provoquer une explosionLaisser une batterie dans un environnement ambiant à température extrêmement élevée qui peut entraîner une explosion ou une fuite de liquide ou de gaz inflammable.Une batterie soumise à une pression d'air extrêmement basse pouvant entraîner une explosion ou une fuite de liquide ou de gaz inflammable.



www.invue.com
NA / LATAM // 704.752.6513 • 888.55.INVUE
EMEA // +31.23.8900150
APAC // +852.3127.6811